

# Quickstart

1		2	
		<b>Effectuer la purge de l'installation</b> Bleed the installation Die Installation entlüften Efectuar la purga de instalaci3n Effettuare lo spurgo dell'impianto Laat de installatie doorspoelen	
			
3			
	<b>Vérifier la présence du (des) joint(s) filtre(s) sur le(s) flexible(s).</b> Check the presence of the filter seal(s) on the flexible hose(s). Einbau der filterdichtung(en) auf dem (die) Schlauch (Schläuchen) überprüfen. De aanwezigheid van def ltering (en) op de slang (en) controleren Verif car la presencia de la (las) junta(s) de filtro(s) sobre el (los) flexible(s). Controllare la(le) guarnizione(i) filtro su ogni flessibile		
4 (Option  )		5	
			
6		7	
			

# PRESTO®

Q509-7 ind.2